PREemp

Concentrated Multi-Surface One Step Disinfectant Cleaner formulated with (AHP)



WHY CHOOSE PREempt™?

- **CLEANER** Effective disinfectant as well as a cleaner resulting in added confidence
- **FASTER** Rapid and realistic contact times on a broad spectrum of difficult to kill pathogens.
- **RESPONSIBLE** Designed to be easier on surfaces, staff and occupants. Users are not exposed to VOCs (volatile organic compounds) and PPE** is not required for in use solutions as per health and safety rating.
- and oxygen leaving no active residues which helps to reduce environmental impact.

SUSTAINABLE The active ingredient, Hydrogen Peroxide, breaks down into water

DIRECTIONS FOR USE

Use Dilutions Made Easy

RATIO	PER GALLON OF WATER	PER 32OZ / 1 QUART OF WATER
1:16	8oz.	2oz.
1:64	2oz.	0.5oz.
1:128	1oz.	0.25oz.
1:256	0.5oz.	N/A

For Use As A One-Step Cleaner/Disinfectant:

- 1. Dilute at 8.0 oz. of product per gallon of water (1:16 dilution).
- 2. Pre-clean heavily soiled areas.
- 3. Apply Use Solution by trigger sprayer to hard, non-porous environmental surfaces. Spray 6-8 inches from surface; making sure to wet surfaces thoroughly.
- 4. All surfaces must remain wet for 5 minutes.
- 5. Wipe surfaces and let air dry with clean cloth.

PREempt™ Surface Disinfectants are designed to protect your staff, patients and business with easy to use disinfectant solutions that are gentle on people, surfaces, and devices.

AVAILABLE PRODUCTS

PREempt™ Concentrate Multi-Surface One-Step Disinfectant Cleaner

EPA REG. NO. 74559-4

SHELF LIFE: 3 Years, 90 Days Diluted

CONCENTRATION OF ACTIVE:

4.25% Hydrogen Peroxide (Concentrated)



*Virucidal: 5 Min. (1:16-1:64 dilution)

- *Minute virus of mice
- *Canine parvovirus
- *Poliovirus Type 1
- *Human Coronavirus
- *Influenza Type A2 (Hong Kong)
- *Norovirus (Feline Calicivirus as the surrogate)
- *Hepatitis B Virus (HBV)
- *Hepatitis C Virus (HCV)
- *HIV-1 (AIDS Virus)
- Kills *Influenza A Virus (H1N1) when used as directed on hard, non-porous inanimate surfaces with a 1 minute contact time.

Bactericidal: 5 Min. (1:16 dilution)

- Pseudomonas aeruginosa
- · Salmonella enterica
- Staphylococcus aureus

Antibiotic-Resistant Bactericidal Activity:

- Staphylococcus epidermidis (MRSE)
- Methicillin-resistant Staphylococcus aureus (MRSA)
- · Vancomycin-resistant Enterococcus faecalis (VRE)
- Klebsiella pneumonia (Carbapenem-resistant [KPC])
- Escherichia coli (Extended Spectrum Beta-lactamase resistance [ESBL])

Fungicidal: 5 Min. (1:16 dilution)

• Trichophyton mentagrophytes

Non-Food Contact Surface Sanitizer: 3 Min. (1:128 dilution)

- Klebsiella pneumoniae
- Salmonella enterica (formerly known as Salmonella choleraesuis)
- Pseudomonas aeruginosa
- Staphylococcus aureus
- Escherichia coli

Non-Food Contact Surface Sanitizer: 30 Sec. (1:16 dilution)

- Klebsiella pneumoniae
- Salmonella enterica (formerly known as Salmonella choleraesuis)
- Pseudomonas aeruginosa
- Staphylococcus aureus
- Escherichia coli



PREempt™ Concentrate

Multi-Surface One-Step

Disinfectant Cleaner is a gentle

and fast concentrate disinfectant

solution that doesn't sacrifice

performance for health and

safety profile, providing a fast

solution not requiring the use

of PPE for in-use solutions.

*Please refer to reference sheet for a complete list of pathogenic organisms, additional features, and claims.

 $PREempt^{\mathsf{TM}}$ branded products are manufactured by Virox Technologies Inc.

Accelerated Hydrogen Peroxide® (AHP®) and PREempt™ are registered trademarks of Virox Technologies Inc.



For more information on this or our other products, visit:



